ROCKY'S EAZY ROLLERS® INSTRUCTIONS - #4A PERMANENT

I his box contains the					
ITEM		DESCRIPTION	RE- ORDER#	Assemble adjustable tubes according to "adjustable tube instructions" included in tubi	Bolt the castors (item #209) to the A-frames (item #55), as shown in the diagram.
# 1	12	Self-tapping Screw	501	box. Insert a 3" hub (item # 69) into one end of	(57) (10) (71) (71) (71) Assemble one end unit to the tube, using
5	2	5/16"x1" Bolt	505	adjustable tubing.	ne Note: APPLY PETROLEUM BASED GREASE. (105) (10
7	4	3/8"x1" Bolt	507		Assemble the other end unit to the tube,
15	4	Concrete Anchor	515		using the white knob (item #61). For smoother operation, apply
19	2	5/16" Washer	505	SMALLER DIAMETER TUBE	petroleum based grease between the
21	4	3/8" Washer	21	With 2 self-drill/tapping	hub (item #65) and the black bushing (item #105). This should be done once a
57	2	#4 A-Frame	531	screws (item #1), attach hub SELF to tube using electric drill. DRILLIN	(69) vear.
61	1	White Knob	533	Apply pressure to (1) 🙀	Position the assembled roller unit at the
69	2	3" Hub Small Handle	543	ensure screw cuts into	widest end of the pool.
71 101	10	Male Grommet	545 549	cuts it's own thread.	VERY IMPORTANT
101	10	Female Grommet	549	(No predrilling required)	PREVENT DROWNING
105	2	Plastic Bushing	555	Repeat with other side.	Attach Warning Label to one end of tube.
107	2	Plastic Washer	555		
201	1	22' Strapping	587		5 Drive the concrete anchor into 6 Insert the 2/01 halts
Tools Required:				For regular shaped pools, align the outside edge of the tube parallel with the end of the pool.	 5 Drive the concrete anchor into the hole with a hammer. Leave the anchor raised 1/16". To set the concrete anchor tap it into the the hole with a hammer. Then using a center punch or large nail drive the slug down into the anchor forcing legs out into concrete. 6 Insert the 3/8" bolts (item #7) through the 3/8" washers (item #21), through the #4 A-frames (item #57) and into the concrete anchors (item #15). Tighten the 3/8" bolts.
Reversible Drill				-	Hit center slug with hammer &
1/2" Concrete (masonary) Drill Bit				For irregular shaped pools, the outside edge of the tube	• Slug center punch,or
Hammer & Center Punch (or nail)			ail)	should be 3' Using the	wo holes of the #4 A-frame (item #57) 1/16" large nail.
5/16" Hex Head Socket Bit				from the frame. W	th a 1/2" concrete drill bit, drill a 1 1/2"
1/2" Wrench 9/16" Wrench				end of deep hole the pool.	at each mark.
T9605074A					

