



SPA FROG BROMINE CARTRIDGE SYSTEM

WHEN TO DO IT	WHAT TO DO
Start Up	<ul style="list-style-type: none"> • Balance pH and Alkalinity • Set Spa Frog to 4 or 5 • 100g of Non-Chlorine Shock (4 Caps) • 60mL of Metal Guard (6 Caps)
After Each Use	<ul style="list-style-type: none"> • Set Spa Frog to 2 or 3 • ½ - 1 Cap of Non Chlorine Shock
Weekly	<ul style="list-style-type: none"> • Test the water and balance according to your test strips • 100g of Non Chlorine Shock (4 Caps) • 30mL of Metal Guard (3 Caps)
Every 2 - 3 Weeks	<ul style="list-style-type: none"> • Remove Filter Cartridges and clean with a hose or a cartridge cleaner solution
Every 3 Months	<ul style="list-style-type: none"> • Prepare hot tub for draining by removing and soaking filter cartridges in a cartridge cleaner solution or purchase new filters • Add 250mL of Whirlpool Rinse and run the jets for 2 hours. Drain and refill the hot tub • Replace Nature2 Clarifier Spa Stick

IDEAL RANGES

Bromine	3-5ppm
Alkalinity	80-120ppm
Phosphates	0-500 ppb
pH	7.2 - 7.8
Calcium	100-300 ppm

Please Note:

The level the Spa Frog has to be set will be bather load dependent. The more people and longer the hot tub is in use, the higher the Spa Frog has to be set level will be.

A spa frog should last 1 – 2 months.

All chemicals should be poured near the filters for even distribution, with the jets on high or by activating a clean cycle. All air jets should be turned off.

Always wait 30 minutes to use the hot tub after applying chemical treatments. A longer wait may be required if bromine or pH Down have been added.

**QUESTIONS?
WE CAN HELP!**