

Section 9. AquaPure® Exploded View and Replacement Kits

9.1 AquaPure Control Centre Replacement Parts

Dwg.#	Kit #	Description	Qty.	Dwg.#	Kit #	Description	Qty.
1	R0467400	User Interface Board Screws	1 4	5	R0503400	Face Plate, Control Centre, APURE-F Mounting Bracket, User Interface, APURE-F	1 1
2	R0467800	Screws, User Interface, PureLink™ Screws, Power Interface Assy Screws, Bezel Cover Plate Screws, Bezel Support Plate Screw, Battery Cover	4 2 2 2 2 1			Screws, User Interface Mounting Bracket and Face Plate Battery Door, Control Centre, APURE-F Screw, Battery Cove	4 1 1
3	R0447500	Wiring Harness, PureLink Back PCB to DC Cord	1	6	R0503300	Battery Door, Control Centre, APURE-F Screw, Battery Cover	1 1
4	R0467600	Power Interface Board Assembly Screws, Power Interface	1 2				




Figure 17. AquaPure® Control Centre

9.2 3-Port Electrolytic Cell and Sensor Replacement Parts with Universal Unions (2"-2½")

Dwg. #	Kit #	Description	Qty.
1	R0452100	Universal Union/Tailpiece/Plug, 3-Port Cell includes: Nut, Union Universal O-Ring, #2-231 Tailpiece, 2" X 2 ½" Plug, Port CG Cell	3 3 2 1
2	R0452200	O-Rings and Terminal Adapter, 3-Port Cell includes: O-Ring, #2-231 O-Ring, #2-106 Terminal Adapter Screw, #6 X 1/2"	3 6 1 2
3	R0452401	14-Blade Cell, 3-Port Cell Includes: Cell Assy, Apure O-Ring, #2-231 DC 16' Power Cord, Black	1 3 1
4	R0452501	Port Sensor 16' w/O-Ring, 3-Port Cell	1
5	R0476400	Port Sensor 25' w/O-Ring, 3-Port Cell	1
6	SP3PC	3-Port Spool Cleaning Kit includes: Spool, GC Cell, 3-Port O-Ring, #2-231 Nut, Union Universal Tailpiece, 2" X 2½" Plug, Port CG Cell	1 4 3 2 2
7	R0402800	16' Cable DC	1
8	R0476300	25' Cable, DC	1




Figure 18. 3-Port Electrolytic Cell and Sensor Exploded View (Universal Unions)




Figure 19. 3-Port Spool Exploded View